



Cable feeding tool **EZ.SPEEDY**

The **smart** and **easy** way to feed cable into micro-ducts.




Facts

- Tool to push cables (from \varnothing 0.5 mm up to max. 8.0 mm) into micro-ducts
- Fast, easy and safe (no bending)
- Easy to handle
- To be used with a cordless drill
- Ideal for the "Last Mile"
- Lightweight and compact
- Ready for use in seconds
- Available for cable dimensions:
 - ✓ 0,5-1.0 mm
 - ✓ 1.0-2.0 mm
 - ✓ 2.0-3.0 mm
 - ✓ 3.0-4.0 mm
 - ✓ 4.0-5.0 mm
 - ✓ 5.0-6.0 mm
 - ✓ 6.0-7.0 mm
 - ✓ 7.0-8.0 mm



Standard kit in single plastic or upgrade carry case

- ✓ 1 EZ.SPEEDY pusher (basic body)
- ✓ 2 rubber rolls according to selected cable dimension
- ✓ 2 cable guides according to selected cable dimension
- ✓ 5 tube couplings (6,8,10,12 und 14 mm)
- ✓ 1 tube reductor 8/7mm
- ✓ 1 coupling front
- ✓ 1 Hex Bit holder 8 mm
- ✓ 1 Allen key 5 mm
- ✓ 1 wrench 8 mm
- ✓ 1 small container with spare screws
- ✓ 1 operating manual



SWISSMADE

Cable feeding tool **EZ.SPEEDY**

Scope

The perfect tool for feeding fiber optic cables (Ø 0.5 mm to 8.0 mm) into micro-ducts. Connect the EZ.SPEEDY to a standard cordless drill and start pushing cables soft and safely (without bending) into micro-ducts. In connection with the EZ.BOOSTER you are able to blow the cable even more smoothly and evenly. Insertion length up to 500 m. Ideal for the "Last Mile".

Application

- Select and assemble rubber roller according to selected cable dimension.
(appropriate cable dimension is stamped into aluminum ring of rubber roller)
- Select and assemble cable guide according to cable dimension
- Next steps:

<i>EZ.SPEEDY</i>	<i>EZ.SPEEDY in combination with EZ.BOOSTER</i>
<ul style="list-style-type: none"> • Screw on the tube coupling • Connect to micro-duct • Fit hex bit holder to cordless drill • Control/select speed torque • Insert fiber optic cable through cable guide (insert approx. 1 m) • Close EZ.SPEEDY handles • Fit cordless drill to one of the hex screws and start operating the drill • Cable will be inserted into micro-duct 	<ul style="list-style-type: none"> • Prepare EZ.BOOSTER to be used with EZ.SPEEDY (violet connection plate) • Connect micro-duct to EZ.BOOSTER • Screw on coupling front to EZ.SPEEDY • Connect EZ.SPEEDY to EZ.BOOSTER • Fit hex bit holder to cordless drill • Controle/select speed torque • Pass cable through cable guide (insert approx. 1 m) • Close EZ.SPEEDY handles • Connect pressed air hose to EZ.BOOSTER and switch on compressor • Fit cordless drill to one of the hex screws and start operating the drill • Cable will be blown smoothly and evenly into micro-duct



EZ.SPEEDY Video

